

Complement of Technical Service No 31

Important recommendations on the use of Seastar Seven keys

How to remove the crystal from a Seastar Seven

1. Place the watch, dial down, into the special tool.
2. Turn the knurled knob which tightens the jaws just enough to grip and hold the crystal.
3. Reverse the tool placing the back of the watch near the surface of the bench and tap one case lug lightly with a wooden mallet. The crystal will be released easily from the case.

Caution

Because of the superior construction of all Seastar crystals which are fitted with inner tension rings, do not tighten the jaws of the tool in an effort to reduce the crystal diameter. This will crack the crystal, or distort the tension ring.

This tool is designed only to hold the crystal and retain it while it is tapped from the case.

To fit the crystal to the case

Do not increase the tension on the jaws of the gripping tool.

Place the crystal, in the tool, in position over the case and apply light even pressure. Once alignment is assured press firmly to seat crystal fully and evenly over outer circumference.